DUROVIN
BATHROOMS

IMPORTANT SAFETY NOTES

•Under no circumstances should you attempt to drill through the glass, damage or injury may occur
•Please handle all glass with care, avoiding knocks and shock loading to all sides and edges. Safety glass cannot be reworked.
•Care should be taken when drilling into walls to avoid hidden pipes or electrical cables.



Scan this QR code for installation video.

Sliding Door With Soft Close Instructions

Tools Required



Two people required. We recommend that a technically competent installer should undertake this installation.

Be sure you have all included parts and tools required before beginning installation and that you have plenty of space for assembly.

PRE-INSTALLATION AND TECHNICAL REQUIREMENTS

- All dimensions are shown in millimetres, except where otherwise indicated.
- Ensure that the enclosure set is fitted to a level floor and vertical wall surface.
- This instruction manual is applicable for both pre-tiled wall and plain walls.
- The wall fixings included with this product are suitable for solid walls only. Plasterboard or stud walls may require specialist fixings (not supplied).
- Due to the possibility of residual spray, the area around the outside of the shower tray should be tiled, or made otherwise water resistant.

IMPORTANT SAFETY NOTES

- Under no circumstances should you attempt to drill through the glass, damage or injury may occur
- Please handle all glass with care, avoiding knocks and shock loading to all sides and edges. Safety glass cannot be reworked.
- Care should be taken when drilling into walls to avoid hidden pipes or electrical cables.


2-3M




10
9
11
8
12
7
6
13
14
15
5
4
3
2
1


800MM-1000MM
2-3M
450mm
450mm
450mm
200mm
H+59mm mini
H+64mm maxi
Ø8
30mm
Ø6




10mm


16mm
8mm