





DUROVIN
BATHROOMS




Ravenna 26 Double Door

Tools Required




Silicone Gun



Tape Measure



Scissors




Philips Screwdriver



Hammer



Allen Keys



Drill Bit



Pencil



Power Drill



Level

Two people required. We recommend that a technically competent installer should undertake this installation.

Be sure you have all included parts and tools required before beginning installation and that you have plenty of space for assembly.

If you have ordered this shower enclosure with one of our shower trays, **please note** that tiling should be done before the shower tray is installed. This is so that the shower tray can be pushed up against the tiles and sealed with silicone.


PRE-INSTALLATION AND TECHNICAL REQUIREMENTS

















- All dimensions are shown in millimetres, except where otherwise indicated.
- Ensure that the enclosure set is fitted to a level floor and vertical wall surface.
- This instruction manual is applicable for both pre-tiled wall and plain walls.
- The wall fixings included with this product are suitable for solid walls only. Plasterboard or stud walls may require specialist fixings (not supplied).
- Due to the possibility of residual spray, the area around the outside of the shower tray should be tiled, or made otherwise water resistant.


IMPORTANT SAFETY NOTES

- Under no circumstances should you attempt to drill through the glass, damage or injury may occur
- Please handle all glass with care, avoiding knocks and shock loading to all sides and edges. Safety glass cannot be reworked.
- Care should be taken when drilling into walls to avoid hidden pipes or electrical cables.


Included Parts




Ref	Description	Illustrations	Qty	Ref	Description	Illustration	Qty
①	Fixing Piece		1	⑨	Seals		2
②	Seals		4	⑩	Hinges		4
③	Weather Bar		2	⑪	Seals		2
④	Fixing Pieces		R/L *1	⑫	Handles		2
⑤	Glass Side Panels		2	⑬	Glass Doors		2
⑥	Aluminium Profiles		2	⑭	ST4*16		7
⑦	Caps		2	⑮	Wall Plugs		11
⑧	Caps		4	⑯	ST4*30		8




1. Measure the size of your shower enclosure against the walls.




2. Place the aluminium profiles against the walls, marking where holes will be drilled.




3. Drill holes and insert wall plugs.
4. Screw the aluminium profiles onto the walls.



5. Insert the glass side panels into the aluminium profiles.
6. Attach the hinges to the glass side panels.




7. Position the glass doors, attaching them to the hinges.





8. Attach the side seals to the glass doors.

Align the side seals with the vertical edges of the glass doors and carefully press or slide them into position from top to bottom.




Ensure the seals fit tightly against the glass with no twisting, gaps, or deformation. Trim any excess length if necessary.





9. Attach the bottom seals to the glass doors and side panels.

Fix the bottom seals onto the lower edges of the glass doors and the side glass panels.




Check that the seals are straight and securely fitted.






10. Attach the side seals to the glass doors.

Mark the fixing positions on the aluminium profiles, and secure them to the side panels, then drill pilot holes using a suitable drill bit.




Align the profiles with the side panels and fasten them using screws. Tighten carefully to avoid damaging the glass or aluminium.



11. Insert caps to cover the holes.


Once all screws are fully secured, insert the cover caps into the screw holes in the aluminium profiles.






12. Insert caps on top of both aluminium profiles.






Fit the caps onto the top ends of both aluminium profiles, pressing them firmly into place to ensure a secure and neat finish.



13. Position the glass fixing pieces and mark the drilling locations.

Place the glass fixing pieces in their correct positions against both glass panels. Carefully align them and mark the points where holes need to be drilled on each side, ensuring accurate positioning.






14. Drill the holes and insert wall plugs.

Using a suitable drill bit, drill holes at the marked locations. Clean out any dust, then insert the wall plugs fully into the holes to provide secure fixing points.

15. Install the weather bars and secure the fixing pieces.

Position the weather bars correctly, aligning them with the fixing pieces. Fasten the fixing pieces using screws, tightening securely while ensuring the weather bars remain straight and properly aligned.



16. Attach the handles to the glass doors.
17. Silicone and allow to dry for 24 hours.